



Mid Hinged Column (Raising & Lowering Procedure)

Step (1)

Ensure that the wind conditions are still. Attach a 12mm or larger diameter double braided rope to the rope tie, which is located at the base of the skirt. The rope must be at least two meters longer than the height of the entire column. Columns of height greater than 20M require two ropes with two operators acting in unison. As a precaution, in case the counterweight balance has not been installed, temporarily tie a short piece of rope around the column, threading it through the same rope tie at the base of the skirt and tie each end together to form a circle. Be sure to leave at least one meter of slack.

Step (2)

Release the Allen Keyed skirt securing bolt and pull the skirt away from the column. Be sure **(NOT)** to remove the fixings that have the "Do Not Remove" Washers, as these hold the counter weight in place. If the skirt can be held by hand, it is now safe to remove the short piece of rope from around the column and begin lowering the column, whilst holding firm on the long rope.

Step (3)

Pull the skirt away from the stub section and lower the column slowly and steadily avoiding any jerking movements, which may damage the light fitting(s), other equipment or column. Lower the column until the light fitting(s) or equipment are at a safe working height. Be careful not to lower the column fully as the lights or equipment may hit the ground or base section of the column. Now tie the end of the rope to the rope tie at the base of the column and commence the required work. To prevent rope burns, ensure suitable rope handling gloves are worn at all times.

Step (4)

Reverse the procedure to raise the column and ensuring skirt bolt is secured and fastened before untying the rope from the rope tie.

